



***To avoid problems during application, please thoroughly and completely read these instructions at least once before you begin the process of applying Moby Grip Surf Traction to your surf board.**

Application Instructions




1. Position Moby Grip on the surf board in the area to which it will be applied.


To ensure adhesion, clean this region with Goo-Gone and gently wipe it down with rubbing alcohol.




2. Peel 1.5" of the Moby Grip pad from the release paper covering the adhesive backing.




3. Fold over the 1.5" of paper covering. Use the exposed adhesive to hold the desired position of the Moby Grip, tapping it gently against the board.



4. Lift the other end of the pad from the paper backing. Fold the paper under, leaving pad exposed.



5. With the paper backing tucked under, place pad back in its original desired position. Smooth the traction pad against the board.



6. Find the folded edge of the release paper under the unsecured side of the pad. Pull the paper slowly up and outward. Allow the Moby Grip pad to relax against the board.



7. Once the paper has been removed and the pad is in position, press firmly to board. Always press away from the center and toward the edge to eliminate air bubbles between the traction pad and the board.